

**Red Star Tec Wireless PowerPoint & Keynote Presentation Remote Clicker (PR-819)**



User Guide / Benutzerhandbuch/ Guía del usuario/ Guida utente/ Guide de l'utilisateur



**ENGLISH**

# **Box Contents**

**1 x Red Stvar Tec PR-819 presentation remote**

**1 x Manual - (User Guide)**

**1 x Protective case**

**1 x USB Wireless Receiver**

## **System Requirements**

**For PC's - Windows 10 or previous versions**

**For Mac's - Mac OS X or previous versions**

**Or**

**Linux, Android OS**

**USB port (with standard USB interface)**

## **Specification**

**Height - 1 inch 2.2 cm**

**Length - - 4.5 inches -11 cm**

**Weight - 0.4 lbs - 180 grams**

**Working range - 50 foot - 15 metres with 2.4 GHz wireless technology**

**Battery-power indicator**

**On/Off switch**

# Installation



No software is needed for the PR-819 to work as a remote control for presentations. Simply remove the USB receiver found at the base of the presenter and plug this into your USB port of your MAC or PC.

Next insert 2 AAA batteries into your PR-819 battery compartment and turn on your the remote clicker. The power indicator will illuminate when one of the (next slide, previous slide, launch slide show or black slide keys are used).

# Using the Presenter

Once the presentation remote clicker and the USB are connected you can use the PowerPoint remote clicker to advance slides in your PowerPoint and Keynote presentations as desired.

There are 5 functional buttons on the presenter.

1. The Laser pointer which can be used to highlight and point to text/images within your presentation as required.
2. The Next slide key, advances to the next slide in both Keynote and PowerPoint
3. The Black Screen key (A PowerPoint & PC only feature). This will allow your screen to go black as if you had pressed the F key to allow the screen to go blank on a PC. This is useful when you want the audience to focus on you and not your presentation.
4. The Launch Slide Show key (A PowerPoint and PC only feature). This allows you to go from the slides directly into the Slide Show mode from the presentation remote clicker.
5. The Previous slide key, this will allow you to go from your current slide to your previous slide as required


## FOR MAC USERS

For some Mac users you may find that the presentation clicker does not appear to work when first plugged into your MAC. A message indicating that the device is not recognized by your MAC will appear.

This message occurs as the Keyboard setup of the MAC is not the set up by default in the same way as a PC. You will then need to use the Keyboard Setup Assistant to remap your keyboard and allow your MAC to recognize the presenter.


# How to use the Keyboard Setup Assistant to identify your keyboard

1. Insert the USB receiver of the PowerPoint clicker.




2. Press the shift key & the key immediately to the right of the shift Key on the left side of your Mac keyboard simultaneously. This is usually the (~) key (See the image above).

3. You will then see a message that states your keyboard cannot be identified.



4. Select the SKIP option

5. The Keyboard Setup Assistant will then prompt you to select your preferred (Keyboard Type).



6. Select the ANSI (United States and Others) option

7. Once you have selected the ANSI keyboard option click the done option

8. Once you have changed your keyboard type. You should find that your USB receiver is recognized. Confirm this by switching on the clicker and launching a PowerPoint or Keynote slide show your slides should now go forward & back as desired.

9. You are now ready to use your presentation clicker.

*We welcome your feedback and you can let us know your ideas at [support@redstartec.com](mailto:support@redstartec.com)*