



**RED STAR TEC**

# **BOOMSOUNZ RST T90 WIRELESS EARBUDS**

**(FULL MANUAL)**



[SUPPORT@REDSTARTEC.COM](mailto:SUPPORT@REDSTARTEC.COM)



[WWW.REDSTARTEC.COM](http://WWW.REDSTARTEC.COM)



Thank you for choosing a Red Star Tec product. We value your decision and are delighted to welcome you as a new user. Our goal is to provide you with an outstanding experience through our products and services.

We invite you to share your feedback and suggestions with us through our social media channels, or our email. Your insights help Red Star Tec continually improve our products and services.

If you encounter any issues while using the product, please refer to our service process. Your support is our greatest strength, and your recognition and evaluation are a tremendous encouragement to Red Star Tec. Thank you!



[Red Star Tec](#)



[RedStarTec](#)



[withredstartec](#)



[support@redstartec.com](mailto:support@redstartec.com)


# ACCESSORIES LIST:




CHARGING CASE



EARBUDS



TYPE C CHARGING CABLE



QUICK GUIDE



EARBUDS TIPS

# DEVICE COMPATIBILITY:



SMARTPHONE  
(ANDROID, IPHONE)



LAPTOPS  
(MACBOOKS, WINDOWS)



TABLET  
(IPAD, ANDROID TABLET)

**+ OTHER DEVICES THAT SUPPORTS BLUETOOTH**

# OVERVIEW OF HEADSET



## MULTI FUNCTION BUTTON COMMANDS

### CALL MODE

PRESS ONCE - answer the phone  
PRESS AND HOLD FOR 2 SECS- hang up

### MUSIC MODE

#### PLAY MUSIC

press once on both left and right earbuds

#### PREVIOUS SONG

press twice quickly on left earbud

#### NEXT SONG

press twice quickly on right earbud

#### DECREASE VOLUME

press and hold on left earbud

#### INCREASE VOLUME

press and hold on right earbud

### CHANGE MODE:

press three times quickly on right earbud

### GOOGLE ASSISTANT/ SIRI:

press three times quickly on left earbud

## IMPORTANT!

- If the command you're trying to initiate is not recognized, you will hear beeping sounds. Ensure you are initiating the command properly.
- Switching from Music Mode to Game Mode requires no active multimedia like video or music players. Close all active applications to change modes properly.
- Next and previous song commands cannot be initiated if the music is paused. Play the music again before making another request.
- Digital assistants like Siri and Google Assistant are available only on smartphones, not on laptops.
- Play and pause are available on YouTube both in the smartphone app and website version on a laptop. Next and previous commands work on YouTube if the videos/music are in a playlist.
- The earbuds support AAC, which provides high-quality audio encoding. Check if your phone supports AAC and enable it under Bluetooth options by selecting the earbuds and looking for the AAC option.

# USER GUIDE

## Turning ON/OFF

- **Power On:** The headset will automatically turn on when removed from the charging case if it is charged and activated. You can also turn it on manually by pressing and holding the multi-function key for 3 seconds when the headset is off.
- **Power Off:** The headset will automatically turn off when placed back into the charging case and the lid is closed. Additionally, when the headset is not connected to a device, you can turn it off by pressing and holding the multi-function key for 5 seconds.

## Pairing

### • Single Earbud Connection

1. Remove one earbud from the charging case.
2. Enable Bluetooth on your mobile device and search for the pairing name "**BOOMSOUNZ**". Click to connect. When the earbud connects successfully, the white light will flash continuously, and you will hear a prompt tone saying "Connected."

### • Two Earbuds Connection

1. Remove both earbuds from the charging case. They will power on and connect automatically. The master earbud's blue and white lights will flash alternately as they enter pairing mode. (The earbuds are now ready to pair with your device.)
2. Enable Bluetooth on your phone or other Bluetooth devices, search for "**BOOMSOUNZ**", and click to connect. When the Bluetooth connection is successful, you will hear "Connected."

- **PAIRING SUCCESSFUL:** The "Left" earphone's white indicator will flash slowly, and the "R" earphone's blue and white lights will alternate. The earbuds are now ready to connect to your mobile device. If pairing is not successful, place both earbuds back into the charging case and then remove them again.
- **ONE EARBUDS IS NOT CONNECTING:** If one of your earbuds has no sound while connected to your phone, you can resolve this by turning off Bluetooth on your phone and placing the earbuds back into the charging case. After taking them out again, the earbuds will successfully pair within 10 seconds, indicated by a continuous white light flashing.

## Reconnecting

The earbuds will automatically reconnect to previously paired devices when turned on, provided that the devices' Bluetooth is enabled and the pairing record still exists.

**Note:** There may be instances where the earbuds do not automatically reconnect, especially if they were previously used with other devices. The earbuds prioritize the last connected device. If you want to use them with a specific device and they do not reconnect automatically, you can manually go to the Bluetooth settings of that device, find the earbuds in the list, and reconnect.

## Button Functions

- **Answer the phone** - press MFB (either left or right)
- **Reject the phone call** - Press and Hold the MFB (either left or right)
- **Play/ Pause Music** - press MFB (either left or right)
- **Increase Volume** - Press and Hold Right MFB(Play status)
- **Decrease Volume** - Press and Hold the Left MFB(Play status)
- **Next Song** - Press Twice the Right MFB (Play status)
- **Previous Song** - Press Twice the Left MFB (Play status)
- **Voice Assistant Access** -press the L MFB three times
- **Game Mode ON/OFF** - press Right MFB three times

## Indicator Light Status

### Earbuds

- When charging, the blue light is on.
- Once fully charged, the light turns off.
- During pairing, the blue and white lights flash.

### Charging Case

- When charging, the red light flashes slowly.
- Once fully charged, the red light remains on.
- When the battery is low, the green light blinks slowly.
- During discharge, the green light flashes continuously.

# PRODUCT FEATURES

- **Advanced Bluetooth 5.3 Technology:** Enjoy low power consumption and superior compatibility with a wide range of devices, ensuring a seamless and stable connection.
- **Environmental Noise Cancellation (ENC):** Advanced ENC technology reduces background noise for clearer calls and a more immersive listening experience.
- **Game Mode:** Activate Game Mode for a low-latency audio experience, perfect for a more immersive and responsive gaming session.
- **Voice Assistant Compatibility:** Easily access your favorite voice assistants, such as Siri or Google Assistant, with a simple touch, allowing you to control your device hands-free.
- **Enhanced Durability:** The headphone PCBA features advanced waterproof and sweatproof treatment, providing excellent protection against moisture for worry-free use during workouts and in various weather conditions.
- **Versatile Ear Cap Options:** The ear caps are easily removable, offering both in-ear and semi-in-ear wearing styles for a customizable and comfortable fit.
- **Quick Charge Capability:** Charge your headphones for just 10 minutes to enjoy up to 3 hours of playback, ensuring you're never without your music for long.
- **Supports AAC (Advanced Audio Coding) codec:** improves the audio quality by providing high-quality audio encoding for your earbuds. This codec can offer better sound performance compared to other codecs, especially if your earbuds support AAC playback. (note: this feature is only available if your device supports AAC codec)

## SPECIFICATIONS

### Bluetooth Specifications

- Bluetooth Version: V5.3 (AD6973D4)
- Supported Protocols: HSP, HFP, A2DP, AVRCP
- Bluetooth Operating Frequency: 2.402 GHz - 2.480 GHz
- Transmission Distance: Up to 10 meters

## Battery and Charging

- Standby Time: Up to 200 hours
- Talk Time: Up to 7 hours
- Music Playback Time: Up to 6 hours
- Charging Time: Approximately 1.5 hours
- Charging Voltage: DC 5V
- Earbuds Battery Capacity: 35 mAh each
- Charging Case Battery Capacity: 300 mAh

## Audio Specifications

- Frequency Response Range: 20 Hz - 20 kHz

# TROUBLESHOOTING (FAQS)

### Why is my earbud not working ?

Make sure that you already paired your earbuds with your device. You can take out both earbuds from the charging case and the master earbud's blue and white lights will flash alternately as they enter pairing mode. (The earbuds are now ready to pair with your device.) Enable Bluetooth on your phone or other Bluetooth devices, search for " **BOOMSOUNZ** ", and click to connect. When the Bluetooth connection is successful, you will hear "Connected."

### Why is there no sound from one earbud?

If one earbud has no sound while connected to your phone, try turning off Bluetooth on your phone and placing the earbuds back in the charging case. Then, take them out again. The earbuds should pair successfully within 10 seconds, indicated by the white light flashing continuously.

### Why can't I reconnect with my earbuds?

If both earbuds are unable to automatically pair (indicated by both earbuds flashing blue and white lights alternately), place them back into the charging case and then remove them. The earbuds will automatically pair with each other without any further action needed.



### **Why is the indicator light not responding?**

If the earphone's indicator light does not respond, press the Multi-Function Button (MFB) in either Left or Right earbuds for 8 seconds to reset it.

### **Why is my earbuds' charging case not charging correctly?**

If the charging case is not charging properly, ensure that the USB Type-C connector is securely plugged in. Additionally, regularly clean the USB port on the charging case to prevent dust buildup, which can lead to charging malfunctions.

### **Why can't I switch from music mode to game mode?**

To enable this feature, please close all active applications. Once all applications are closed, quickly tap the right MFB three times. You should then hear a prompt saying 'game mode'.

### **Can I use the play and pause functions on YouTube?**

Yes, the play and pause functions work on YouTube both in the smartphone app and on the website version on a laptop. Next and previous commands work if the videos/music are in a playlist..

### **Why do I hear beeping sounds when trying to initiate a command?**

Beeping sounds indicate that the command is not being recognized. Ensure you are initiating the command correctly.

## **SAFETY AND MAINTENANCE**

**To ensure the longevity and optimal performance of your product, please follow these guidelines:**

- **Keep Dry:** Ensure the product remains dry and avoid placing it in humid environments to prevent short circuits.
- **Avoid Extreme Heat:** Do not expose the product to direct sunlight or high temperatures. Excessive heat can shorten the lifespan of electronic components, damage the battery, and deform plastic parts.
- **Protect from Cold:** Avoid exposing the product to cold conditions to prevent damage to the PCB board.
- **Do Not Disassemble:** Refrain from attempting to disassemble the product, especially if you are not a professional, to avoid voiding the warranty and causing potential damage.

- **Handle with Care:** Be careful when handling the product to prevent falls, strong vibrations, or impacts from hard objects, which could damage the internal electronic circuitry.
- **Clean Gently:** Use a soft, dry cloth for cleaning. Avoid using harsh chemicals or detergents that could damage the product.
- **Prevent Scratches:** Avoid scratching the surface with sharp objects to maintain the appearance and integrity of the case.
- **Optimal Charging:** Do not charge the product continuously for more than 10 hours to prevent battery degradation and extend its lifespan.
- **Regular Maintenance:** Periodically check and clean the charging ports and ear tips to ensure proper functionality and hygiene.

By following these safety and maintenance tips, you can help prolong the lifespan of your product and ensure it continues to perform at its best.

## WARRANTY INFORMATION:

Your boomsounz earbuds comes with a standard 6-month warranty. For extended coverage up to 12 months, register your product on our website.

## CUSTOMER SUPPORT

For any inquiries, technical support, or assistance with your earbuds, please contact our customer support team. We're here to help!

- **Email:** [support@redstartec.com](mailto:support@redstartec.com)
- **Website:** [www.redstartec.com](http://www.redstartec.com)

**SPECIAL OFFER**

# Thank You for Choosing BoomSounZ RST T90 Wireless Earbuds!

As a token of our gratitude, claim a one-time coupon code for a discount on your next purchase of our wireless earbuds or any other Red Star tec products !

## How to Claim Your Coupon Code:

**OPTION 1:** Visit Our Website and fill out the details:

<https://redstartec.com/TY-discount>

**OPTION 2:** Scan the QR Code:

- Use your smartphone's camera to scan the QR code which would direct you to website and fill up your details.
- Fill out the required details.



**DISCOUNT  
COUPON CODE**